

## Secure Meters Liberty 100 Quick Start Commissioning Process

1. Once meter has been installed, please ensure that the WAN light is flashing before you begin the commissioning process.
2. When the WAN light is flashing, press 0 to wake the display.
3. To commence commissioning – **Press A.**



4. Bypass entering MPAN – **Press B.**



5. Bypass testing switching device – **Press B.**



6. The meter will then perform a WAN and signal check. The following screens will be displayed:



Followed by



7. Take note of the signal strength and antenna type displayed:

No Signal  
00 – 05 Poor  
06 – 11 OK  
12 – 31 Good

8. Based on the results, if the antenna type and signal strength is found appropriate for WAN registration, then proceed to step 10. If not, you will need to connect an external aerial.

9. If you need to connect an external aerial, switch antenna type to 'External' - **Press A.**



10. If you are not connecting an 'External' aerial, leave antenna type on 'Internal' - **Press B.**

11. Bypassing adding HAN device – **Press B.**



13. Complete commissioning process with WAN – **Press A.**



Followed by



12. If commissioned successfully, end the process – **Press A.**

#### **Connect Pipit (IHD) to the meter:**

Installer, please provide MeterPay the PIPIT(IHD) Mac address.

- a. With the pipit powered on select Settings > Info,
- b. Mac address will be displayed, record the information, example: B879-7E00-0040-412A,
- c. Record serial number of the meter that the Pipit will be paired with.