



Setting the RFID meter Daily Standing Charge

Place the Programming Card over the front of the meter where it says 'Hold Card Here'



Until the LCD display shows the following:



Remove the Programming Card and press the **RED** button until you see the 'Standing Charge' LCD display, as shown below.

The number of times you need to press the **RED** button will depend on whether your meter is set with a Single Rate or Two Rate Tariff:

- Single Rate Tariff - press 29 times
- Two Rate Tariff - press 34 times



To change the value, use the **BLUE** button to alter the number of the flashing digit, and then press the **RED** button to move to the next digit to the right.

Once the daily amount has been set, press the **RED** button until you see the End screen:

