
# Energy Management Energy Meter Type EM111





- Easy connection or wrong current direction detection
- Other versions available (not certified, option X: see "how to order" on the next page

- Single phase energy meter
- Class 1 (kWh) according to EN62053-21
- Class B (kWh) according to EN50470-3
- Accuracy ±0.5% RDG (current/voltage)
- Direct current measurement up to 45AAC
- Backlit LCD display with integrated touch key-pad
- Energy readout on display: 7 digit
- Variable readout on display: 4 digit
- Energy measurement: kWh and kvarh (imported/ exported); kWh+ by 2 tariffs
- System variables, kW, kvar, V, A, PF, Hz, kWdmd, kWdmd peak
- Self power supply
- Dimensions: 1-DIN module
- Protection degree (front): IP51
- Pulse output (optional, by opto-mosfet)
- RS485 Modbus port (optional)
- M-bus port (optional)
- Digital input (for tariff management)

#### **Product description**

Single-phase energy meter with backlit LCD display with integrated touch keypad. Particularly indicated for active energy metering and for cost allocation in

applications up to 45 A (direct connection), with dual tariff management availability. It can measure imported and exported energy or be programmed to

consider only the imported one. Housing for DIN-rail mounting, with IP51 front degree protection. The meter is optionally provided with pulse output proportional to the active energy being measured, RS485 Modbus port or M-bus port. Available for legal metrology (PF option, only for imported energy).

## **STANDARD**

Not certified according to MID Directive. Cannot be used for fiscal (legal) metrology.

HOW IO Order	EMITT-DIN AVOIN OIN
Model —	
Range code ———	
System —	
Power supply ——	
Output —	
Option —	

How to order EMILLIAND AVO I VOI V

## **Type Selection**

Rang	e code	Syst	tem	Pow	er supply	Outp	out
AV8:	230VLN AC - 5(45)A (Direct connection)	1:	1-phase 2-wire	X:	Self power supply -30% +20% of the	O1: S1:	pulse output RS485 Modbus port
AV7:	120VLN AC - 5(45)A (Direct connection)				rated measuring input voltage, 45 to 65Hz	M1: M-bus port	
Optio	on						
X:	none						

# Input specifications

Rated Inputs	
Current type	1-phase loads, direct
	connection
Current range	5(45)A
Nominal voltage	230VLN AC (AV8 option),
	120 VLN (AV7 option)
Accuracy	
(@25°C ±5°C, R.H. ≤60%,	
45 to 65 Hz)	
AV7	Imin=0.25A; Ib: 5A, Imax:
	45A; Un: 120VLN -30%
	+30%
AV8	Imin=0.25A; lb: 5A, Imax:
	45A; Un: 230VLN -30%
	+20%
Current (AV7, AV8)	From 0.04lb to 0.2lb:
	±(0.5%RDG+1DGT)
	From 0.2lb to lmax:
	±(0.5%RDG)
Phase-neutral voltage	In the range Un: ±(0.5%
	RDG)
Frequency	Range: 45 to 65Hz.
Active power	From 0.05 In to Imax,
	within Un range, PF=1:
	±(1% RDG)
	From 0.1 In to Imax, within
	Un range, PF=0.5L or 0.8C:
	±(1% RDG)
Power factor	±[0.001+1%(1.000 - "PF
	RDG")]
Reactive power	From 0.05 In to Imax,
	within Un range, sinphi=1:
	±(2% RDG)
	From 0.1 In to Imax, within
	Un range, sinphi=0.5L or
Enganaire	0.8C: ±(2% RDG)
Energies	Class 1 seconding to
Active energy	Class 1 according to EN62053-21
Pagativa aparav	
Reactive energy	Class 2 according to EN62053-23
Start-up current	20mA (AV7, AV8)
Start-up current:	Self-consumption is not
	measured.
Start-up voltage	84VLN (AV7), 161VLN (AV8)
Resolution	OTVERV (NV), TOTVERV (AVO)
(also via serial port)	
Current	0.1A
Voltage	0.1V
Power	0.1kW or kvar
Frequency	0.1 Hz
PF	0.01
Energies (positive)	0.01kWh or kvarh (display:
	autoranging up to 1 kWh
	or kvarh) 0.01kWh or kvarh
	(serial comm.)
	,

Energies (negative)	0.1kWh or kvarh (display: autoranging up to 1 kWh or kvarh) 0.01kWh or kvarh (serial comm.)
Energy additional errors	
Influence quantities	According to EN62053-21
Temperature drift	≤200ppm/°C
Sampling rate	4096 samples/s @ 50Hz 4096 samples/s @ 60Hz
Display and touch key-pad	
Type	Backlit LCD, 7-digit, h 6
	mm
Read-out	Energy: 8 digit. Variables: 4 digit
Touch key	2 (Enter and UP). Scolling
rodon noy	the keys up and down the
	functions UP and DOWN
	can be carried out
Max. and Min. indication	Max. 999 999.9
Max. and Min. indication	Min. 0.0
Memory energy storage	141111. 0.0
Energy	10^10 cycles. Energy value
Lifergy	is saved every time the less
	significant digit increases.
Programming parameters	10^10 cycles. When a
r rogiamining parameters	parameter is modified, only
	the relevant memory cell is
	overwritten
LEDs	Flashing red light pulses
LLD3	according to EN50470-3,
	EN62052-11, 1000 imp./
	kWh (min. period: 90ms)
	Fix orange light: wrong
	current direction (only
	with PF option or with "B"
	measurement selection in
	case of X option)
Current overloads	oudo of A option)
Continuous	45A, @ 50Hz
For 10ms	1350 A
Voltage Overloads	1000 A
Continuous	1.2 Un
For 500ms	2 Un
	2 011
Input impedance	
Voltage input 230VL-N	1.2 Mohm
Voltage input 120VL-N	1.2 Mohm
Current inputs: 5(45) A	< 0.5 VA

# Digital input specifications

**Digital inputs** 

Function

Number of inputs Contact measurement voltage 5 V Input impedance

Contact resistance

Free of voltage contact Tariff management (switch between t1-t2)

1kohm

1kohm, close contact

Overload

100kohm, open contact In case a voltage is erroneously applied to the digital input, the input is not damaged up to 30 VAC/DC.

## **Output specifications**

RS485 serial port	RS485 by screw	Secondary address	Univocally defined in each
•	connection.	•	unit
Function	For communication	Identification number range	from 5000 0000 to 6999
	of measured data,		9999
	programming parameters	Other	Available functions: wild
Protocol	ModBus RTU (slave		card, header, initialisation
	function)		SND_NKE, and req_udr
Baud rate	9.6, 19.2, 38.4, 57.6, 115.2		management. Management
	kbaud, even or no parity,		of primary address
Address	1 to 247 (default: 01)		modification via M-bus and
Driver input capability	1/8 unit load. Maximum		reset of partial energy via
	247 transceivers on the		M-bus available.
5	same bus.		VIF, VIFE, DIF and DIFE:
Data refresh time	1sec	<del></del>	see protocol
Read command	50 words available in 1	Static output	Faurules subsub
Du/Tu in dia ation	read command	Purpose	For pulse output
Rx/Tx indication	Rx segment on display is shown when a valid		proportional to the active
		Pulse rate	energy (kWh)
	Modbus command is sent	Puise rate	Selectable in multiple of 100
	to that specific meter  Tx segment on display		Max 1000 or 3000 kWh
	is shown when a valid		according to pulse ON
	Modbus reply is sent back		duration
	to the master	Pulse ON duration	Selectable: 30ms or 100
M-bus port	M-bus by screw	Fulse ON duration	ms according to EN62052-
M-bus port	connection.		31
Function	For communication of	Output type	Opto-mosfet
Tunction	measured data	I oad	V <sub>ON</sub> 2.5 VAC/DC max.
Protocol	M-bus according to	Load	100mA
1 1010001	EN13757-1		V <sub>OFF</sub> 260 VAC max.
Baud rate	0.3, 2.4, 9.6 kbaud		OFF 200 V/ Co Max.
Meters in the M-bus network	250		
Primary address	Selectable		
y dadi ooo			

# **General specifications**

Operating temperature	-20 to +65 °C, indoor, (R.H. from 0 to 90% non- condensing @ 40°C)	Standard compliance Safety	IEC60664, IEC61010-1 EN60664, EN61010-1
Storage temperature -30°C to +80°C (R.H. < 90% noncondensing @		Metrology	EN62052-11 EN62053-21, EN50470-3
	40°C)	Approvals	CE (cULus pending)
Installation category	Cat. III (IEC 60664, EN60664)	Connections Cable cross-section area	Measuring inputs: max. 6
Insulation (for 1 minute)	4000 VAC RMS between measuring inputs and digital/serial output (see table) 4000 VAC RMS	Other terminals	mm² with/without metallic cable ferrule; Max. screw tightening torque: 1.1 Nm 1.5 mm², Min./Max. screws tightening torque: 0.4 Nm
Dielectric strength	4000 VAC RMS for 1 minute	Housing Dimensions (WxHxD)	17.5 x 63 x 90 mm
EMC Electrostatic discharges Immunity to irradiated	According to EN62052-11 15kV air discharge; Test with current: 10V/m	Material  Sealing covers	Noryl, self-extinguishing: UL 94 V-0 Included
•	from 80 to 2000MHz;	Mounting	DIN-rail
Electromagnetic fields  Burst	Test without any current: 30V/m from 80 to 2000MHz;	Protection degree Front Screw terminals	IP51 IP20
20.00	Burst On current and voltage measuring inputs circuit: 4kV		Approx. 80 g (packing included)
Immunity to conducted disturbances	10V/m from 150KHz to 80MHz		
Surge	On current and voltage measuring inputs circuit: 4kV;		
Radio frequency	According to CISPR 22		

# **Power supply specifications**


Self power supply		Power consumption	≤ 1.0W, ≤ 8VA
AV8	230VAC VL-N, -30% +20%		
	50/60Hz		
AV7	120VAC VL-N, -30% +30%		
	50/60Hz		

### Insulation (for 1 minute) between inputs and outputs


	Measuring input	Auxiliary power supply	Digital or serial output	Digital input
Measuring input	-	0 kV	4 kV	4 kV
Auxiliary power supply	0 kV	-	4 kV	4 kV
Digital or serial output	4 kV	4 kV	-	4 kV
Digital input	4 kV	4 kV	4 kV	-

## Accuracy (according to EN50470-3 and EN62053-23)

kWh, PF=accuracy (RDG) depending on the current



kvarh, accuracy (RDG) depending on the current



# **Display pages**

No	Variable	"Full" mode	"Easy" mode	Note
0	kWh+ (imported)	X	Х	In PFA version and in X version with Measurement menu set to "A", this is considering the total energy without considering the current direction.
1	kWh- (exported)	X	Χ	Only in X version, with Measurement menu set to "B"
2	kW	X	Χ	
3	V	Х	Х	
4	Α	Х	Х	
5	PF	X		
6	Hz	Х		
7	kvarh+ (imported)	Х		In PFA version and in X version with Measurement menu set to "A", this is considering the total positive reactive energy without considering the current direction.
8	kvarh- (exported)	Х		Only in X version, with Measurement menu set to "B"
9	kvar	Х		
10	kW dmd	Х		
11	kW dmd peak	X		
12	kWh (t1)	X	Х	Only relevant to kWh+, with Tariff menu set to ON
13	kWh (t2)	X	Х	Only relevant to kWh+, with Tariff menu set to ON

X= available

#### List of available menus

Menu name and desc	ription	Range	Default setting
PASS	Password request	From 0000 to 9999	0000
nPASS	New password	From 0000 to 9999	0000
Measure	Measurement type (A=easy connection; B=bidirectional, imported and exported energy).	A; b	А
P int	Integration time for Wdmd calculation	1 to 30 min	1
Mode	Selection of complete or simplified set of variables on display	Full or Easy	Full
Tariff	Tariff enabling	Yes/No	No
Pulse (O1 option)	Selection of pulse ON duration	30 or 100 ms	30
	Selection of the pulse rate	100 to 1000 (if duration is 100ms) or to 3000 (if 30 ms)	100
Address (S1 option)	Modbus serial address	1 to 247	01
Kbaud (S1)	Modbus baud rate	9.6; 19.2; 38.4; 57.6, 115.2 kbps	9.6
Parity (S1)	Modbus parity	No/even	No
Primary address (M1 option)	M-bus primary address	1 to 250	1
Kbaud (M1)	M-bus baud rate	0.3; 2.4; 9.6 kbps	2.4
Reset	Allow the reset of tariff meters and W dmd peak and of the kWh/kvarh partial meter available only via serial communication	Yes/No	No
End	Exit to measuring mode		

Note: after the confirmation of a new parameter value, the value is stored in the memory without the need to exit the programming mode.


## Additional available information on the display (\*)


Туре	Description	Note
Info page 1	Year (2013)	Year of production
Info page 2	Serial (dddnnnA)	Serial number (ddd= day of the year; nnn=progressive number; A= production line, internal use only)
Info page 3	Rev (A.01)	Firmware revision
Info page 4	Measure	Measurement type
Info page 5	P int	Integration time for Wdmd calculation
Info page 6	Mode	Set of variables on display
Info page 7	Tariff	Tariff enabling
Info page 8 (O1)	Pulse	Pulse ON duration
		Pulse rate
Info page 8 (S1)	Address	Modbus serial address
Info page 9 (S1)	Kbaud	Modbus baud rate
Info page 10 (S1)	Parity	Modbus parity
Info page 8 (M1)	Primary address	M-bus primary address
Info page 9 (M1)	Kbaud	M-bus baud rate


<sup>(\*)</sup> can be reached by pressing simultaneously the 2 touch keys


### Wiring diagrams















### Front panel description



#### 1. Display

Backlit LCD display with touch key-pad.

Upper part: enter Lower part: UP

Scroll in up direction: UP Scroll in down direction: DOWN

#### 2. LED

LED proportional to kWh reading

#### 3. Serial number and MID data

Area reserved to serial number and MID-relevant data in PF versions

#### **Dimensions (mm)**

