## Energy Management Energy Meter Type EM112



- Easy connection or wrong current direction detection
- Other versions available (not certified, option X: see "how to order" on the next page

- Single phase energy meter
- Class 1 (kWh) according to EN62053-21
- Class B (kWh) according to EN50470-3
- Accuracy ±0.5% RDG (current/voltage)
- Direct current measurement up to 100AAC
- Backlit LCD display (3x 8-digit) with integrated touch key-pad
- Energy readout on display: 8 digit
- Variable readout on display: 4 digit
- Energy measurement: kWh and kvarh (imported/ exported); kWh+ by 2 tariffs
- System variables, kW, kvar, V, A, PF, Hz, kWdmd, kWdmd peak
- Self power supply
- Dimensions: 2-DIN module
- Protection degree (front): IP51
- Pulse output (optional, by opto-mosfet)
- RS485 Modbus port (optional)
- M-bus port (optional)
- Digital input (for tariff management)

### **Product description**

Single-phase energy meter with backlit LCD display with integrated touch keypad. Particularly indicated for active energy metering and for cost allocation in applications up to 100 A (direct connection), with dual tariff management availability. It can measure imported and exported energy or be programmed to consider only the imported one. Housing for DIN-rail mounting, with IP51 front degree protection. The meter is optionally provided with pulse output proportional to the active energy being measured, RS485 Modbus port or M-bus port. Available for legal metrology (PF option, only for imported energy).

**CARLO GAVAZZI** 

## STANDARD

Not certified according to MID Directive. Cannot be used for fiscal (legal) metrology.

How to order	EM112-DIN AVO 1 X O1 X
Model	
Range code ———	
System ———	
Power supply ——	
Output	
Option	

### Type Selection

Range code		System		Pow	Power supply		Output	
(D <b>AV1:</b> 12	230VLN AC - 5(100)A Direct connection) 20VLN AC - 5(100)A Direct connection)	1:	1-phase 2-wire	X:	Self power supply -30% +20% of the rated measuring input voltage, 45 to 65Hz	O1: S1: M1:	pulse output RS485 Modbus port M-bus port	

#### Option

X: none



## Input specifications

Rated Inputs	d selected to the allocation	Energies (negative)	0.1kWh or kvarh (display:
Current type	1-phase loads, direct connection		autoranging up to 1 kWh or kvarh) 0.01kWh or kvarh
Current range	5(100)A		(serial comm.)
Nominal voltage	230VLN AC (AV0 option),	Energy additional errors	(senar comm.)
Nominal Voltage	120 VLN (AV1 option)	Influence quantities	According to EN62053-21
Accuracy		Temperature drift	≤200ppm/°C
(@25°C ±5°C, R.H. ≤60%,		Sampling rate	4096 samples/s @ 50Hz
45 to 65 Hz)			4096 samples/s @ 60Hz
AVO	Imin=0.25A; Ib: 5A, Imax:	Display and touch key-pad	·
	100A; Un: 120VLN -30%	Туре	Backlit LCD, 3 rows by
	+30%		8-digit each, h 5 mm
AV1	Imin=0.25A; Ib: 5A, Imax:	Read-out	Energy: 8 digit. Variables: 4
	100A; Un: 230VLN -30%		digit
	+20%	Touch key	2 (Enter and UP). Scolling
Current (AV0, AV1)	From 0.04lb to 0.2lb:		the keys up and down the
	±(0.5%RDG+1 DGT)		functions UP and DOWN
	From 0.2lb to Imax:		can be carried out
Phase poutral voltage	$\pm$ (0.5%RDG) In the range Un: $\pm$ (0.5%	Max. and Min. indication	
Phase-neutral voltage	RDG)	Energies	Max. 9 999 999
Frequency	Range: 45 to 65Hz.		Min. 0.01
Active power	From 0.05 In to Imax,	Variables	Max. 9999
	within Un range, PF=1:	Manager	Min. 0.01
	±(1% RDG)	Memory energy storage Energy	10^10 cycles. Energy value
	From 0.1 In to Imax, within	Ellergy	is saved every time the less
	Un range, PF=0.5L or 0.8C:		significant digit increases.
	±(1% RDG)	Programming parameters	10^10 cycles. When a
Power factor	±[0.001+1%(1.000 - "PF	· · · · · · · · · · · · · · · · · · ·	parameter is modified, only
	RDG")]		the relevant memory cell is
Reactive power	From 0.05 In to Imax,		overwritten
	within Un range, sinphì=1:	LEDs	Flashing red light pulses
	±(2% RDG)		according to EN50470-3,
	From 0.1 In to Imax, within Un range, sinphi=0.5L or		EN62052-11, 1000 imp./
	0.8C: ±(2% RDG)		kWh (min. period: 90ms)
Energies			Fix orange light: wrong
Active energy	Class 1 according to		current direction (only
, lear e energy	EN62053-21		with PF option or with "B" measurement selection in
Reactive energy	Class 2 according to		case of X option)
	EN62053-23	Current overloads	
Start-up current:	40mA (AV0, AV1)	Continuous	100A, @ 50Hz
	Self-consumption is not	For 10ms	3000 A
	measured.	Voltage Overloads	00007
Start-up voltage	84VLN (AV1), 161VLN (AV0)	Continuous	1.2 Un
Resolution		For 500ms	2 Un
(also via serial port)	0.14	Input impedance	
Current	0.1A 0.1V	Voltage input 230VL-N	1.2Mohm
Voltage Power	0.1v 0.1kW or kvar	Voltage input 120VL-N	1.2Mohm
Frequency	0.1 Hz	Current inputs: 5(100) A	< 1.25VA
PF	0.01	• • • • •	
Energies (positive)	0.01kWh or kvarh (display:		
	autoranging up to 1 kWh		
	or kvarh) 0.01kWh or kvarh		
	(serial comm.)		

# **Digital input specifications**

Digital inputs	Free of voltage contact	Overload	100kohm, open contact
Function	Tariff management (switch		In case a voltage is
	between t1-t2)		erroneously applied to
Number of inputs	1		the digital input, the input
Contact measurement voltage	5 V		is not damaged up to 30
Input impedance	1kohm		VAC/DC.
Contact resistance	1kohm, close contact		

## **Output specifications**

RS485 serial port	RS485 by screw	Other	Available functions: wild
Function	connection. For communication of measured data, programming parameters		card, header, initialisation SND_NKE, and req_udr management. Management of primary address
Protocol	ModBus RTU (slave function)		modification via M-bus and reset of partial energy via
Baud rate	9.6, 19.2, 38.4, 57.6, 115.2 kbaud, even or no parity,		M-bus available. VIF, VIFE, DIF and DIFE:
Address	1 to 247 (default: 01)		see protocol
Driver input capability	1/8 unit load. Maximum	Static output	
	247 transceivers on the same bus.	Purpose	For pulse output proportional to the active
Data refresh time	1sec		energy (kWh)
Read command	50 words available in 1 read command	Pulse rate	Selectable in multiple of 100
Rx/Tx indication	Rx segment on display is shown when a valid Modbus command is sent		Max 500 or 2000 kWh according to pulse ON duration
	to that specific meter Tx segment on display is shown when a valid	Pulse ON duration	Selectable: 30ms or 100 ms according to EN62052- 31
	Modbus reply is sent back to the master	Output type Load	Opto-mosfet V <sub>on</sub> 2.5 VAC/DC max.
M-bus port	M-bus by screw connection.		100mA V <sub>off</sub> 260 VAC max.
Function	For communication of measured data		
Protocol	M-bus according to EN13757-1		
Baud rate	0.3, 2.4, 9.6 kbaud		
Meters in the M-bus network	250		
Primary address	Selectable		
Secondary address	Univocally defined in each unit		
Identification number range	from 7000 0000 to 7999 9999		



## **General specifications**

Operating temperature	-20 to +65 °C, indoor,	Standard compliance	
	(R.H. from 0 to 90% non-	Safety	IEC60664, IEC61010-1
	condensing @ 40°C)		EN60664, EN61010-1 EN62052-11
Storage temperature	-30°C to +80°C (R.H. <	Metrology	EN62053-21, EN50470-3
	90% noncondensing @ 40°C)	Approvals	CE (cULus pending)
Installation category	Cat. III (IEC 60664,	Connections	
installation category	EN60664)	Cable cross-section area	Measuring inputs: max.
Insulation (for 1 minute)	4000 VAC RMS between		25 mm <sup>2</sup> , min. 5 mm <sup>2</sup> with/without metallic
	measuring inputs and		cable ferrule; Max. screw
	digital/serial output (see		tightening torque: 2.8 Nm
	table) 4000 VAC RMS	Other terminals	1.5 mm <sup>2</sup> , Min./Max. screws
Dielectric strength	4000 VAC RMS for 1		tightening torque: 0.5 Nm
	minute	Housing	
EMC	According to EN62052-11	Dimensions (WxHxD)	35 x 63 x 90 mm
Electrostatic discharges	15kV air discharge;	Material	Noryl, self-extinguishing: UL 94 V-0
Immunity to irradiated	Test with current: 10V/m	Sealing covers	Included
Electromagnetic fields	from 80 to 2000MHz; Test without any current:	Mounting	DIN-rail
Electromagnetic fields	30V/m from 80 to	Protection degree	Birtrai
	2000MHz;	Front	IP51
Burst	On current and voltage	Screw terminals	IP20
	measuring inputs circuit: 4kV	Weight	Approx. 160 g (packing
Immunity to conducted	467	5	included)
disturbances	10V/m from 150KHz to		
	80MHz		
Surge	On current and voltage		
	measuring inputs circuit:		
Radio frequency	4kV; According to CISPR 22		
nadio nequency			

## Power supply specifications

Self power supply		Power consumption	$\leq$ 1.0W, $\leq$ 8VA
AV8	230VAC VL-N, -30% +20%	· · · · · · · · · · · · · · · · · · ·	,
AV7	50/60Hz 120VAC VL-N, -30% +30%		
	50/60Hz		


## Insulation (for 1 minute) between inputs and outputs

	Measuring input	Auxiliary power supply	Digital or serial output	Digital input
Measuring input	-	0 kV	4 kV	4 kV
Auxiliary power supply	0 kV	-	4 kV	4 kV
Digital or serial output	4 kV	4 kV	-	4 kV
Digital input	4 kV	4 kV	4 kV	-

### Accuracy (according to EN50470-3 and EN62053-23)

Percentage error limits for class index B +1.5% +1% 0% -1% -1.5% 100A(I<sub>max</sub>)  $PF=1 0.25A(I_{min}) 0.5A(I_{tr})$ 5A(I<sub>n</sub>) (0,11<sub>ref</sub>) 0.5A(I<sub>tr</sub>) 0.05A(I\_ref) PF=L0.5 5A(I<sub>n</sub>) 100A(I<sub>max</sub>) or C0.8 (0,11<sub>ref</sub>) Class 1 accuracy limits (Active energy) 5(100)A Start-up current: 40mA

kWh, accuracy (RDG) depending on the current



kvarh, accuracy (RDG) depending on the current

### **Display pages**

N	d et	Ond	Ord	"	<b>"F . !</b>	N.L.
No	1 <sup>st</sup> row	2 <sup>nd</sup> row	3 <sup>rd</sup> row	"Full" mode	"Easy" mode	Note
0	kWh+ (imported)		kW	х	×	In PFA version and in X version with Measurement menu set to "A", this is considering the total energy without considering the current direction.
1	kWh- (exported)		kW	Х	X	Only in X version, with Measurement menu set to "B"
2	kWh+ (imported)		V	Х	X	
3	kWh+ (imported)		A	Х	X	
4	kWh+ (imported)		PF	Х		
5	kWh+ (imported)		Hz	Х		
6	kvarh+ (imported)		kvar	х		In PFA version and in X version with Measurement menu set to "A", this is considering the total positive reactive energy without considering the current direction.
7	kvarh- (exported)		kvar	Х		Only in X version, with Measurement menu set to "B"
8	kWh+ (imported)	kWdmd peak	kWdmd	Х		
9	kWh (t1)	"t1"	kW	Х		Only relevant to kWh+, with Tariff menu set to ON.
10	kWh (t2)	"t2"	kW	Х		Only relevant to kWh+, with Tariff menu set to ON.

X= available



### List of available menus

Menu name and desc	ription	Range	Default setting
PASS	Password request	From 0000 to 9999	0000
nPASS	New password	From 0000 to 9999	0000
Measure	Measurement type (A=easy connection; B=bidirectional, imported and exported energy).	A; b	A
P int	Integration time for Wdmd calculation	1 to 30 min	1
Mode	Selection of complete or simplified set of variables on display	Full or Easy	Full
Tariff	Tariff enabling	Yes/No	No
Home	Home page selection (default page at power-on and after 120 s time-out from other pages).	0 to 9	0
Pulse (O1 option)	Selection of pulse ON duration	30 or 100 ms	30
	Selection of the pulse rate	100 to 500 (if duration is 100ms) or to 2000 (if 30 ms)	100
Address (S1 option)	Modbus serial address	1 to 247	01
Kbaud (S1)	Modbus baud rate	9.6; 19.2; 38.4; 57.6, 115.2 kbps	9.6
Parity (S1)	Modbus parity	No/even	No
Primary address M-bus primary address (M1 option)		1 to 250	1
Kbaud (M1) M-bus baud rate		0.3; 2.4; 9.6 kbps	2.4
Reset Allow the reset of tariff meters and W dmd peak and of the kWh/kvarh partial meter available only via serial communication		Yes/No	No
End	Exit to measuring mode		


Note: after the confirmation of a new parameter value, the value is stored in the memory without the need to exit the programming mode.


Туре	Description	Note
Info page 1	Year (2013)	Year of production
Info page 2	Serial (dddnnnA)	Serial number (ddd= day of the year; nnn=progressive number; A= production line, internal use only)
Info page 3	Rev (A.01)	Firmware revision
Info page 4	Measure	Measurement type
Info page 5	P int	Integration time for Wdmd calculation
Info page 6	Mode	Set of variables on display
Info page 7	Tariff	Tariff enabling
Info page 8	Home	Selected home page
Info page 9 (O1)	Pulse	Pulse ON duration
		Pulse rate
Info page 9 (S1)	Address	Modbus serial address
Info page 10 (S1)	Kbaud	Modbus baud rate
Info page 11 (S1)	Parity	Modbus parity
		Stop bit (in case of No parity only)
Info page 9 (M1)	Primary address	M-bus primary address
Info page 10 (M1)	Kbaud	M-bus baud rate


## Additional available information on the display (\*)

(\*) can be reached by pressing simultaneously the 2 touch keys


### Wiring diagrams









The load resistance (Rc) must be designed so that the closed contact current is under 100 mA ( $V_{on}$  is equal to 1 V dc). DC voltage ( $V_{off}$ ) must be less than or equal to 80 V.



serial output must only be terminated on the last network device connecting terminals B+ and T. For connections longer than 1000 m or networks with more than 160 instruments, use a signal repeater.



### Front panel description



- Display Backlit LCD display with touch key-pad. Right key ("E"): enter Left key ("up"): UP Scroll in right direction: UP Scroll in left direction: DOWN
- 2. LED LED proportional to kWh reading
- 3. Serial number Area reserved to serial number

### **Dimensions (mm)**

