# Energy Management Energy Meter Type EM330



- Digital input (for tariff management)
- Easy connection or wrong current direction detection
  Certified according to MID Directive (option PF only): see "how to order" below
- Other versions available (not certified, option X): see "how to order" on the next page

- Three phase energy meter
- Class 1 (kWh) according to EN62053-21
- Class B (kWh) according to EN50470-3
- Accuracy ±0.5% RDG (current/voltage)
- Current measurement via CT
- Backlit LCD display (3x 8-digit) with integrated touch key-pad
- Energy readout on display: 8 digit
- Variable readout on display: 4 digit
- Energy measurement: kWh and kvarh (imported/ exported); kWh+ by 2 tariffs; kWh per phase
- System variables: kW, kvar, kVA, VLL, VLN, PF, Hz, kWdmd, kWdmd peak
- Phase variables: kW, kvar, kVA, VLL, VLN, A, PF
- Auxiliary power supply
- Dimensions: 3-DIN module
- Protection degree (front): IP51
- Pulse output (optional, by open collector PNP)
- RS485 Modbus port (optional)
- M-bus port (optional)
- Run hour meter
- Neutral current calculation

#### **Product description**

Three-phase energy meter with backlit LCD display with integrated touch keypad. Particularly indicated for active energy metering and for cost allocation (CT connection), with dual tariff management availability. It can measure imported and exported energy or be programmed to consider only the imported one. Housing for DIN-rail mounting, with IP51 front degree protection. The meter is optionally provided with pulse output proportional to the active energy being measured, RS485 Modbus port or M-bus port. Available for legal metrology (PF option, only for imported energy).

**CARLO GAVAZZI** 

	Certified according to MID Directive, Module B
MID	and Module D of Annex II, for legal metrology
	relevant to active electrical energy meters
see Ar	nex V, MI003, of MID). Can be used for fiscal
legal) ı	netrology.

#### How to order EM330 DIN AV5 3 H O1 PF B

Model Range code	
System	
Power supply	
Output	
Option	
Measurement ——	

#### **Type Selection**

Range code		Syst	em	Pow	er supply	Outp	ut
AV5:	400 VLL AC - 5(6)A (CT connection)	3:	3-phase, 3 or 4 wire	H:	auxiliary power supply 90 to 260 V ac/dc	O1: S1: M1:	pulse output RS485 Modbus port M-bus port

#### Option

**PF:** Certified according to MID Directive. Can be used for fiscal (legal) metrology.

#### Measurement

A: The power is always integrated (both in case of positive imported and negative exported power) and the total energy meter is certified according to MID.

**B:** Only the total positive energy meter is certified according to MID.



#### How to order EM330 DIN AV5 3 H O1 X STANDARD Model Range code -Not certified according to MID Directive. Cannot be used System for fiscal (legal) metrology. Power supply -Output -**Option**

# **Type Selection**

Range code		System		Power supply		Output	
AV5:	400 to 480 VLL ac - 5(6)A (CT connection) 230 to 277 VLN ac - 5(6)A (CT connection)	3:	3-phase, 3- or 4-wire; 2-phase 3-wire, 1-phase 2 wire	H:	auxiliary power sup- ply 100 to 240V ac/dc	O1: S1: M1:	pulse output RS485 Modbus port M-bus port

#### Option

**X**: none

# Input specifications

Rated Inputs		Temperature drift	≤200ppm/°C
Current type	3-phase loads, CT	Sampling rate	4096 samples/s @ 50Hz
	connection		4096 samples/s @ 60Hz
Current range	5(6)A	Display and touch key-pad	
Nominal voltage	AV5: 400 to 480 VLL ac	Туре	Backlit LCD, 3 rows by
Max CTxVT	AV5: 1000	.)/	8-digit each, h 7 mm
Accuracy		Read-out	Energy: 8 digit. Variables: 4
(@25°C ±5°C, R.H. ≤60%,			digit
45 to 65 Hz)		Touch key	3 (DOWN, Enter and UP).
	AV5: Imin=0.25A; In: 5A,	Max. and Min. indication	
	Imax: 6A; Un: 230 to 277	Energies	Max. 99 999 999
	VLN (400 to 480 VLL)		Min. 0.01
Current	From 0.04In to 0.2In:	Variables	Max. 9999
	±(0.5%RDG+1DGT)		Min. 0.01
	From 0.2In to Imax:	Memory	
Dhace neutral valters	±(0.5%RDG)	Energy	10^12 cycles. Energy value
Phase-neutral voltage	In the range Un: $\pm (0.5\% \text{ RDG})$		is saved every time the less
Phase-phase voltage	In the range Un: ±(1% RDG) Range: 45 to 65Hz.		significant digit increases.
Frequency Active power	From 0.05 In to Imax,	Programming parameters	10^12 cycles. When a
Active power	within Un range, PF=1:		parameter is modified, only
	±(1% RDG)		the relevant memory cell is
	From 0.1 In to Imax, within		overwritten
	Un range, PF=0.5L or 0.8C:	LEDs	
	±(1% RDG)	Flashing red light pulses	Proportional to the product
Power factor	±[0.001+1%(1.000 - "PF RDG")]		of the CT and VT ratios
Reactive power	From 0.05 In to Imax,	Weight (pulses/kWh) 1	> 700,1 (CT x VT)
·	within Un range, sinphì=1:	Weight (pulses/kWh) 10	70.1–700 (CT x VT)
	±(2% RDG)	Weight (pulses/kWh) 100	7.1–70 (CT x VT)
	From 0.1 In to Imax, within	Weight (pulses/kWh) 1000	< 7.1 (CT x VT)
	Un range, sinphì=0.5L or	•	
	0.8C: ±(2% RDG)	Duration	90ms
Energies		Fix orange light	wrong current direction
Active energy	Class 1 according to		(only with PFB option or
	EN62053-21 and MID Annex MI-003 Class B		with "B" measurement
	(Class B (kWh) according		selection in case of X
	to EN50470-3)		option)
Reactive energy	Class 2 according to	Current overloads	
Redelive energy	EN62053-23	Continuous	6A, @ 50Hz
Start-up current:	10mA	For 500ms	5 In
Start-up voltage	90VLN	Voltage Overloads	
Resolution	Display	Continuous	1.2 Un
Current	0.1 A	For 500ms	2 Un
Voltage	0.1 V	Input impedance	
Power	0.01 kW or kvar	230VL-N	1.2 Mohm
Frequency	0.1 Hz	5(6) A	< 0.072 VA per channel
PF	0.01	Wrong connection detection	Installation guide to
Energies (positive)	0.01 kWh or kvarh		indicate if connections are
Energies (negative)	0.01 kWh or kvarh		correctly carried out. Can
Ourseast	Serial communication	Dhaaa aaguanaa	be disabled.
Current	0.001 A 0.1 V	Phase sequence	Indicates if the phase sequence is not the correct
Voltage Power	****		one (L1-L2-L3)
	0.1 W or var 0.1Hz	Correct current direction	Indicates if the current
Frequency PF	0.001		direction is not the right one
Energies (positive)	0.001 0.001 kWh or kvarh		(only with PFB option or
Energies (positive)	0.001 kWh or kvarh		with type "B" measurement
Energy additional errors			selection in case of X
Influence quantities	According to EN62053-21		option).



### Input specifications (cont.)

Load conditions	The wrong connection detection works in case of loads with: - PF>0.766 (<40°) if inductive or PF>0.996 (<5°) if capacitive - a current at least equal to	are summed to increase the total postive energy totalizer (kWh+), while the others increase the total negative totalizer (kWh-). Ex. P L1= +2kW, P L2 . +2kW,
Energy metering	10% rated current in every measuring interval the single phase energies with positive sign	P L3 = -3 kW Integration time = 1 hour +kWh = $(2+2) \times 1h = 4 \text{ kWh}$ -kWh = 3 x 1h= 3kWh

# **Digital input specifications**

Digital inputs Function	Free of voltage contact Tariff management (switch between t1-t2)	Contact resistance Overload	≤1kohm, close contact ≥100kohm, open contact In case a voltage is
Number of inputs	1		erroneously applied to the
Contact measurement voltage	5 V		digital input, the input is not
Input impedance	1kohm		damaged up to 30 V ac/dc.

### **Output specifications**

RS485 serial port	RS485 by screw	Meters in the M-bus network	250
-	connection.	Primary address	Selectable
Function	For communication	Secondary address	Univocally defined in each
	of measured data,		unit
	programming parameters	Identification number range	from 9000 0000 to 9999
Protocol	ModBus RTU (slave		9999
	function)	Other	Available functions: wild
Baud rate	9.6, 19.2, 38.4, 57.6, 115.2		card, header, initialisation
	kbaud,		SND_NKE, and req_udr
Data format	even or no parity,		management. Management
Address	1 to 247 (default: 01)		of primary address
Driver input capability	1/8 unit load. Maximum 247		modification via M-bus and
	devices on the		reset of partial energy via
	same bus.		M-bus available.
Data refresh time	1sec		VIF, VIFE, DIF and DIFE:
Read command	50 words available in 1		see protocoll
	read command	Static output	
Rx/Tx indication	Rx segment on display	Purpose	For pulse output
	is shown when a valid		proportional to the active
	Modbus command is sent		energy (kWh)
	to that specific meter	Pulse rate	Selectable in multiple of
	Tx segment on display		100
	is shown when a valid		Max 500 or 1500 kWh
	Modbus reply is sent back		according to pulse ON
	to the master		duration
M-bus port	M-bus by screw		Note: max CTxVT x pulse
	connection.		ratio 20000 (e.g.: if pulse
Function	For communication of		ratio is set to 1000, CTxVT
	measured data		max = 20)
Protocol	M-bus according to		
	EN13757-1		
Baud rate	0.3, 2.4, 9.6 kbaud		

# **Output specifications**

Weight (pulses/kWh) 1 Weight (pulses/kWh) 10 Weight (pulses/kWh) 100	· · · ·	Pulse ON duration Output type Load	Selectable: 30 ms or 100 ms according to EN62052-31 Open collector PNP $V_{ON}$ 1 V dc max. 100mA $V_{OFF}$ 80 V dc max.
Weight (pulses/kWh) 1000	) < 7.1 (CT x VT)		

# **General specifications**

Operating temperature	-25 to +65 °C (-13 to 149°	Standard compliance	
	F), indoor, (R.H. from 0 to	Safety	EN62052-11
	90% non-condensing @	Metrology	EN62053-21, EN50470-3
	40°C)	Approvals	CE, MID (PF option only),
Storage temperature	-30°C to +80°C (-22 to		cULus (UL61010-1)
	176° F) (R.H. < 90% non	Connections	
	condensing @ 40°C)	Cable cross-section area	Voltage inputs: max. 4 mm <sup>2</sup> , min. 1 mm <sup>2</sup> with/
Overvoltage category	Cat. III		without metallic cable
Insulation (for 1 minute)	4000 V ac RMS between		ferrule; Max. screw
	measuring inputs and		tightening torque: 0.6 Nm
	digital/serial output (see	Other terminals	1.5 mm <sup>2</sup> , Min./Max. screws
	table) 4000 V ac RMS		tightening torque: 0.4 Nm
Dielectric strength	4000 V ac RMS for 1	Housing	
	minute	Dimensions (WxHxD)	54 x 90 x 63 mm
EMC	According to EN62052-11	Material	Noryl, self-extinguishing:
Electrostatic discharges	15kV air discharge;		UL 94 V-0
Immunity to irradiated	· · · · · · · · · · · · · · · · · · ·	Sealing covers	Included
electromagnetic fields	Test with current: 10V/m	Mounting	DIN-rail
	from 80 to 2000MHz;	Protection degree	
Electromagnetic fields	Test without any current:	Front	IP51
	30V/m from 80 to	Screw terminals	IP20
-	2000MHz;	Weight	Approx. 240 g (packing
Burst	On current and voltage	Weight	included)
	measuring inputs circuit: 4kV		moladody
Immunity to conducted	460		
disturbances	10V/m from 150KHz to		
distansarroos	80MHz		
Surge	On current and voltage		
č	measuring inputs circuit:		
	4kV;		
Radio frequency	According to CISPR 22		



### Power supply specifications

Auxiliary power supply

H: 100 to 240 V ac/dc


**Power consumption** 

 $\leq$  1W,  $\leq$  8VA

### Insulation (for 1 minute) between inputs and outputs


	Measuring input	Digital or serial output	Digital input
Measuring input	-	4 kV	4 kV
Digital or serial output	4 kV	-	0 kV
Digital input	4 kV	0 kV	-

### Accuracy (according to EN50470-3 and EN62053-23)



kWh, accuracy (RDG) depending on the current

 $\boldsymbol{kvarh},$  accuracy (RDG) depending on the current



# **Display pages**

1 <sup>st</sup> row	2 <sup>nd</sup> row	3 <sup>rd</sup> row	"Full" mode	"Easy" mode	Note
kWh+ (imported)		kW system	Х	Х	In case of Measurement set to "A", total energy without considering the current direction.
kWh- (exported)		kW system	Х	Х	Only with Measurement set to "B"
kWh+ (imported)		V L-L system	Х	Х	
kWh+ (imported)		V L-N system	Х	X	
kWh+ (imported)		PF system	Х		
kWh+ (imported)		Hz	Х		
kvarh+ (imported)		Kvar system	Х	X	In case of Measurement set to "A": total positive reactive energy without considering the current direction.
kvarh- (exported)		Kvar system	Х	Х	Only with Measurement set to "B"
kWh+ (imported)		kVA system	Х		
kWh+ (imported)	kWdmd peak	kWdmd	Х		
kWh (t1)	"t1"	kW system	Х	Х	Only relevant to kWh+, with Tariff menu set to ON.
kWh (t2)	"t2"	kW system	Х	X	Only relevant to kWh+, with Tariff menu set to ON.
kWh L1	kWh L2	kWh L3	Х		In case of Measurement set to "A", total energy without considering the current direction. In case of Measurement set to "B", only imported energy.
kVA L1	kVA L2	kVA L3	Х		
kvar L1	kvar L2	kvar L3	Х		
PF L1	PF L2	PF L3	Х		
V L1-N	V L2-N	V L3-N	Х		
V L1-2	V L2-3	V L3-1	Х		
run hour meter		An	Х		
AL1	A L2	AL3	Х	Х	
kW L1	kW L2	kW L3	Х		


X= available





# Additional available information on the display


Page	Display	Description
Info 1	YEAr (2015)	Year of production
Info 2	SErIAL n (dddnnnA)	Serial number (ddd= day of the year; nnn=progressive number; A= production line, internal use only)
Info 3	rEVISIon (A.01)	Firmware revision
Info 4	PuLS LEd	Pulse rate of front LED (pulse/kWh)
P3	SYStEM	System type
P4	CT ratio	current transformer ratio
P5	VT ratio	voltage transformer ratio
P6	MEASurE (only X option)	Measurement type
P7	InStALL	Wrong connection detection function
P8	P Int	Integration time for Wdmd calculation
P9	ModE	Set of variables on display
P10	tArIFF	Tariff enabling (and current tariff if enabled)
P11	HoME (only X option)	Selected home page
P12-1	PuLSE (O1 option)	Selection of pulse ON duration of output
P12-2	PuLrAtE (O1 option)	Selection of the pulse rate of output
P13	Prl Add (M1 option)	M-bus primary address
P14	AddrESS (S1 option)	Modbus serial address
P15	bAud (M1 or S1)	M-bus or Modbus baud rate
P16-1	PArltY (S1)	Modbus parity
P16-2	StoP blt (S1)	Stop bit (in case of No parity only)
Info 5	Secondary address (M1)	M-bus secondary address


#### Wiring diagrams














### Wiring diagrams (cont.)





### Front panel description



#### 1. Display Backlit LCD display with touch key-pad.

2. LED LED proportional to kWh reading

#### 3. Serial number Area reserved to serial number and MID-relevant data in PF versions

#### **Dimensions**

